


PORTABLE BASKETBALL SYSTEM

. INSTRUCTION .

ZY-001



Warning! Not Suitable for children under 3 years.


Contains small parts and long cord.

This product should only be used under direct adult supervision.

This product should be assembled by an adult.




A Backboard




x1

B Rim




x1

C Base




x1

F Top Pole




x1

E middle Pole



x1

D Bottom Pole



x1

G Rubber Ring




x2

H Base Cap



x1

I Nut




M 8 x 4

J Washer



M 8 x 4

M8 x 40mm



1

x4




WARNING



- Manufacturer recommends filling the base with sand, not water. If you choose to use water, ALWAYS check for leaks. Leaking water will lighten the base and cause the system to become unstable and tip over.
- Empty water completely from the base, or add 2 gallons (7.57 liters) of anti-freeze, before the temperature approaches or falls below the freezing point. Freezing water may crack the base and cause leaks. This will result in failure of the system, and could result in serious injury.
- For residential use only! NOT for commercial use! DO NOT use this product for other than its intended purpose. Any commercial, public, or institutional use voids all warranties.

STEP 1

1. Insert the bottom pole (F) into the groove of base (C), then to cover the rubber ring (G) on middle pole (E) in order to adjust the height when the middle pole insert the bottom pole.
2. Attach the rim (B) and top pole (D) on the backboard (A) at the joint using four bolts(1) through four washers (J) and four nuts (I).



3. Cover the rubber ring on the top pole , then to insert the top pole in middle pole.