

ASSEMBLY INSTRUCTIONS

STEP 1:Place the jogger in the normal use position.Remove the LEG CAPS(4) from two of the LEGS(3) Slide the HANDRAIL SUPPORTS(9) onto the two LEGS(3) Press the LEG CAPS(4)-back on these LEGS(3). Do not tighten the LOCKING KNOBS(2) until STEP 3.

STEP 2:Insert both ends of the TOP HANDRAIL(6) into the LEFT and RIGHT HANDRAILS(7,8) and lock with the BUTTON PINS(5). Make the holes in the LEFT and RIGHT HANDRAILS(7,8) face toward the jogger. Insert the LEFT and RIGHT HANDRAILS(7,8) into the HANDRAIL SUPPORTS(9) and lock in position with the ADJUSTMENT KNOBS(1).

NOTE: These are Marks on the LEFT and RIGHT HANDRAILS(7,8) to help to set the height of the handrail.

STEP 3:Stand on the jogger to make all six LEGS(3) and HANDRAIL SUPPORTS(9) set flat on the floor. Tighten all four LOCKING KNOBS(2) to lock the HANDRAIL SUPPORTS(9) in position.

